

SAFETY PRECAUTIONS

- Do not allow the hot kettles to touch the mouth of the bottle. (The bottle may tip over and cause injuries or damage to the bottle.)
- Avoid dropping, hitting or strong shock against the bottle. (It may damage the plastic or stainless steel surface of the bottle and reduce its ability of heat or cold retention.)
- Do not force large ice cubes into the bottle. Forcing or hitting the ice cubes may cause deformation or malfunction of the bottle.
- Do not shake the bottle after pouring hot beverage into the bottle. The pressure inside will increase and the stopper may become difficult to remove.
- The stopper may become difficult to remove when the bottle is filled with hot beverage. If this happens, press the button to open the lid to release pressure before removing the stopper.
- Please make sure the bottle is put upright when stored in a carrying bag to prevent the beverage from spilling.
- The bottle may not be able to fit into the cup holder for certain model of cars.
- Hot tea may discolor if kept for a long period of time in the bottle. It is recommended to use tea bags during the outdoor use.
- Do not place the product with computer, mobile, digital camera and other electronic gadgets. (To avoid water leaks and damaging the gadgets.)
- After cleaning the bottle, wipe off the water on the bottle thoroughly. (There will be water stains or rust spots if not wiped off thoroughly.)
- Wipe off the stopper and spout after cleaning.
- Do not clean with thinner, benzene, abrasive cleaners or other harsh cleaners. (To avoid damaging the bottle.)
- Do not use chlorine bleach. (It may cause rust on the inner surface of the bottle.)
- Do not boil the bottle or use dishwasher or dish-dryer to clean and dry the bottle. (It may cause rust, deformation or damage to the bottle.)

BEFORE CONTACT OUR SERVICE CENTER

Please check your bottle before you contact our service center. If what you encountered is not described below, please contact our service center.

SYMPTOM	CHECK POINT	WAYS TO HANDLE WITH
Water leaks from the lid	Make sure the stopper gasket is placed properly on the lid.	Please refer to the how to install the gasket section in this manual.
	Make sure the safety lock is locked and the stopper is closed securely.	Check the safety lock again and close the stopper properly.
	Is there any dirt on the stopper gasket?	Please refer to the "how to clean section" in this manual.
Bad odor from inner bottle or lid	Did you fill too much water in the bottle?	Please pour out some beverage from the bottle.
	Check if there is any beverage stain on the inner wall of the bottle or gaskets?	Please refer to the how to clean section in this manual to clean the bottle thoroughly. Use vinegar to clean the bottle if the dirt is hard to remove.
Bad hot (cold) retention	Make sure the beverage is hot (or cold) enough in the bottle.	Please pour proper amount of hot (or cold) beverage in the bottle.

※ Stopper gasket, lid gasket and lid set are consumable parts. Please check once every 6 months to 1 year for damage or deterioration.

TO REMOVE RUST SPOTS AND WATER STAINS

You may find rust spots or water stains caused by the impurities in your drinking water. To remove these, fill the bottle with hot water and then add 10% vinegar in it. Put the bottle aside for about 3 hours. After that, wash the interior of the bottle thoroughly with a soft sponge.

- To prevent the unpleasant odor, please clean the bottle thoroughly before and after use.
- Please make sure you clean the bottle with a **soft** sponge to protect the surface of the inner bottle from being scratched.

ABOUT PARTS FOR AFTER SERVICE

We will keep the consumable parts mentioned in this manual for 5 years after we discontinued the production of this model. If you have any questions regarding to our products, please contact the store where you purchase the product or call our Peacock Customer Service Center.

CONSUMABLE PARTS

AML.AMH.AMF.AMW TYPE

Stopper gasket	
Lid gasket	
Lid set (Stopper, Stopper gasket, Lid gasket)	






Peacock

**STAINLESS STEEL BOTTLE
ONE TOUCH MUG**

**AML • AMH
AMF • AMW**

**USER
INSTRUCTION
MANUAL**

Thank you for purchasing our product. Before using this unit, please read the instruction carefully to ensure the best possible performance.




Actual products may vary from the product illustrated.

Please store your instruction manual in a safe place for future reference.

INSTRUCTIONS

1 Remove the stopper unit

Remove the lid set by turning it anti-clockwise.




2 Fill the bottle with hot (cold) beverage

※ To increase the heat (or cold) retention, pour hot (or cold) water into the bottle and preheat (or precool) the bottle for about 1 minute.


※ Please refer to the right drawing for the maximum level of the beverage.

The beverage may overflow from the lid set if too much beverage is filled in the bottle. Please pour out some beverage from the bottle if the beverage above the maximum level.



3 Close the lid set tightly

Turn the lid set clockwise to close the bottle.




4 Open the lid and enjoy your beverage

- Make sure the product is in upright position before unlocking the safety lock.
- Press the push button and open the lid. Tilt the bottle while drinking the beverage.

1 Unlock the "safety lock". Please refer to the drawings below for each model.


2 Press the button to open. Please refer to the drawings below for each model.



Please clean the inner bottle, lid set thoroughly before use.

5 After enjoying your beverage

- After drinking, make sure the bottle is in upright position and then close the lid.
- Lock the safety lock.



HOW TO TAKE CARE OF YOUR MUG

Please remember to clean your mug after every use.

Outer bottle, lid set

Please wash the outer bottle and lid set with warm water and then wipe it with dry cloth.

※ Please remove the lid set before washing.

Inner bottle

Please use a soft sponge with handle to wash the inner bottle thoroughly. It will keep your bottle clean and prevent unpleasant odors.

Gasket

It may cause water leakage if there is a foreign object on the gasket. Remove the gasket from the lid or stopper. Wash with warm water and then wipe the gasket with dry cloth. After that, refer to the "How to install the gasket" section to reinstall the gasket correctly.

WHEN NOT USE THE BOTTLE FOR A LONG TIME

Make sure to clean the beverage stains on the bottle thoroughly. Wipe the bottle with a dry cloth and allow all the parts to air dry before storage.


HOW TO INSTALL THE GASKET

The bottle will leak if the gaskets are not properly installed.

Please read below content carefully to reinstall the lid gasket and stopper gasket after you clean the bottle every time.


Install the lid gasket

Push the lid gasket in as illustrated below.



Install the lid gasket

Ensure the stopper gasket is set properly on the grooves of the stopper.



※ Make sure the gaskets are set securely to prevent beverages from spilling.

IMPORTANT SAFEGUARDS

Do not use this product for any purpose other than keeping beverages warm or cold.

- Keep out of reach of infants and small children. (There is a risk of scalding or injuries.)



- Do not carry this product around in a tilted position.



- Do not place the product near gas stoves, ovens or heaters. (To prevent deformation or discoloration.)



- Be careful not to scald yourself when using the product. Due to the vacuum insulation, the outside of the product will not become hot, while beverage inside remain very hot.



SAFETY PRECAUTIONS

Continued

- Please make sure the stopper gasket and lid gasket are set properly before using the product. (It may cause injuries or burns, or stain the interior of the car or clothes.)
- Always close the lid set securely. And make sure the "safety lock" is locked. (Hot beverages may leak and cause scalding)
- Do not heat in a microwave. (It may cause sparks, deform or discolor the product.)
- Do not disassemble or attempt to repair this product by yourself.
- This product should not be filled with any of the following items:
 - Dry ice or beverages containing carbon dioxide
 The pressure inside the product will increase, causing the lid set hard to open or the beverage to spout out and possibly cause injuries.
- Miso soup or other beverages containing salt
- The salt will stick to the sides of the inner bottle and cause rust.
- Milk based beverages or fruit beverages
- Prolonged storage may spoil the beverage. This will increase the pressure inside the product and cause the beverage to spout out and possibly cause injuries.
- Fruit pulp, tea or other kinds of leaves
- These may cause water leakage and possible malfunctions.
- Do not use the product while driving. To prevent scalds or stain the interior of the car or clothes. Attempting to use the bottle while driving may distract the driver and may lead to serious accidents.
- When using a car cup holder
 - Make sure the cup holder is strong enough to hold the bottle before using. If the cup holder does not hold up, it may cause injuries or burns, or stain the interior of the car or clothes.
- Do not use the hanging-type cup holder that attaches to the window or air vent. The cup holder may fall off.