


HOW TO INSTALL THE GASKET

The bottle will leak if the gaskets are not properly installed.

Please read below contents carefully to reinstall the stopper gasket and mouth gasket after you clean the bottle every time.


To Attach the Stopper Gasket

Ensure the stopper gasket is set properly on the grooves of the stopper.



To Attach the Mouth Gasket

Ensure the mouth gasket is set properly on the grooves of the drinking cap.



※The bottle will leak if the gaskets are not properly installed.

TO REMOVE RUST SPOTS AND WATER STAINS

You may find rust spots or water stains caused by the impurities in your drinking water. To remove these, please follow below instructions to move the rust spots or water stains on your bottle.

- Fill the bottle with hot water and then add 10% vinegar in it.
 - Put the bottle aside for about 3 hours and then wash the interior of the bottle thoroughly with a soft sponge.
 - Dry the bottle thoroughly.
- To prevent unpleasant odor, please clean the bottle thoroughly after use when filling the bottle with tea or contents contain sugar.
 - Be careful not to damage the bottle when cleaning with other products.

BEFORE CONTACT OUR SERVICE CENTER

Please check your bottle before you contact our service center. Please contact our service center, if what you encountered is not described below.

SYMPTOM	CHECK POINT	WAYS TO HANDLE WITH
■ Water leaks from the lid	Make sure the stopper gasket, mouth gasket are installed properly.	Please refer to the how to install the gasket section in this manual.
	Are the lid set, drinking cap set installed properly?	Install the lid set and drinking cap set properly.
	Is there any dirt on the stopper gasket or drinking cap set?	Please refer to the "how to clean section" in this manual.
	Did you fill too much water in the bottle?	Please pour out some beverage from the bottle.
■ Bad odor from inner bottle or lid	Is there any beverage remaining on the drinking cap?	Put the bottle upright for 2~3 seconds after drinking and then close the lid.
	Check if there is any beverage stain on the inner wall of the bottle or on the gaskets?	Please refer to the how to clean section in this manual to clean the bottle thoroughly. Use vinegar to clean the bottle if the dirt is hard to remove.
■ Bad hot (cold) retention	Make sure the beverage is hot (or cold) enough in the bottle.	Please pour proper amount of hot (or cold) beverage in the bottle.

※ Stopper, stopper gasket and drinking cap set and mouth gasket are consumable parts. Please check once every 6 months to 1 year for damage or deterioration.

ABOUT PARTS FOR AFTER SERVICE

We will keep the consumable parts mentioned in this manual for 5 years after we discontinued the production of this model. If you have any questions regarding to our products, please contact the store where you purchase the product or call our Peacock Customer Service Center.

CONSUMABLE PARTS

AAS TYPE	Lid set (Stopper, Stopper gasket)	
AAT TYPE	Stopper gasket	
	Drinking cap (Drinking cap, Mouth gasket)	
	Drinking cap	
	Mouth gasket	

Peacock


STAINLESS STEEL BOTTLE
MUG TYPE

AAS·AAT

USER
INSTRUCTION
MANUAL

Thank you for purchasing our product. Before using this unit, please read the instruction carefully to ensure the best possible performance.

PARTS



Actual products may vary from the product illustrated.

Please store your instruction manual in a safe place for future reference.



THE PEACOCK VACUUM BOTTLE CO.,LTD

5-12-20, Sagisu, Fukushima-ku, Osaka, 553-0002, Japan
E-mail:service@the-peacock.co.jp
http://www.peacock-world.com/

14112C

SAFETY PRECAUTIONS

Do not use this product for any purpose other than keeping beverages warm or cold.

Keep out of reach of infants and small children.



There is a risk of scalding or injuries.

Be careful not to scald yourself when using the product.



Due to the vacuum insulation, the surface of the product will not become hot, while beverages inside remain very hot.

Do not carry the bottle around in a tilted position.



There is a risk of leaking.

Do not place near heat sources such as gas stoves, ovens and heaters.



It may cause deformation or discolor of the bottle.

Do not allow the hot kettles to touch the mouth of the bottle.



The bottle may tip over and cause injuries or damage to the bottle

Avoid dropping, hitting or strong shock again the bottle.



It may damage the bottle and reduce its retention ability.

This product should not be filled with any of the following items:

- Dry ice or beverages containing carbon dioxide**
The pressure inside the product will increase, causing the lid set hard to open or the beverage to spout out and possibly cause injuries.
 - Miso soup or other beverages containing salt**
The salt will stick to the sides of the inner bottle and cause rust.
 - Milk based beverages or fruit beverages**
Prolonged storage may spoil the beverages. This will increase the pressure inside the product and cause the beverage to spout out and possibly cause injuries.
 - Fruit pulp, tea or other kinds of leaves**
These may cause water leakage and possible malfunctions.
 - Please clean your bottle after use when filled with sports drinks.**
Rinse the inside of the bottle as soon as possible after use to prevent rust or pinholes.
- Do not left the beverages inside the bottle for a long period of time.

- Do not remove the sticker on the bottom of the bottle. It may cause malfunction such as rusting or perforation.
- The hot tea will discolor if stored in the bottle for a long period of time. Please use tea bags during your outdoor use.
- The lid will be difficult to open if hot beverage is stored in the bottle for a long period of time. Due to the pressure inside, there will be a "sound" when opening the lid.
- Do not tilt the mug suddenly when drinking with hot beverages. The beverage may spill and cause scalding or stain clothes.
- Do not shake the bottle after pouring hot beverage in the bottle. The pressure inside the bottle will increase and the stopper may become difficult to remove.
- Do not force large ice cubes into the bottle. Forcing or hitting the ice cubes may cause deformation or malfunction of the bottle.
- Attach the drinking cap set and the lid set properly to make sure the beverage do not leak.
- Please make sure the stopper gasket and mouth gasket are set properly before use.
- Do not hold the bottle by the lid set.
- Do not open the lid near face or when the mug is in a tilt position. The beverage may spill and cause scalding.
- Please make sure the bottle is put upright when stored in a carrying bag to prevent the beverage from spilling.
- Do not take the product with computer, mobile, digital camera and other electronic gadgets. (To Avoid water leakage and damage the gadgets.)
- Do not use the product while driving. Attempting to use the bottle while driving may distract the driver and may lead to serious accidents.
- When using with a car cup holder
 - Make sure the strength of the cup holder is sufficient to hold the mug. The mug may fall and cause injuries or stain the interior of the car or clothes.
 - Do not use a hanging-type cup holder that attaches to the window or air vent. The cup holder may fall off.
- Do not disassemble or attempt to repair this product by yourself.
- Do not heat in a microwave. It may cause sparks, deform or discolor.

INSTRUCTIONS

Please clean the inner bottle, drinking cap set, lid set thoroughly before use.

- Remove the lid set and drinking cap set from the bottle**
 - Remove the lid set by turning the lid anti-clockwise.
 - Turn the lid set anti-clockwise
 - Detach
 - Detach the drinking cap set by turning the cap anti-clockwise.

※ It will be easier to detach the cap by turning it upwardly.
- Fill the bottle with hot (cold) beverages**

※ To increase the heat (or cold) retention, pour hot (or cold) water into the bottle and preheat (or precool) the bottle for about 1 minute.

※ Please refer to the right drawing for the maximum level of the beverages.
The beverage may overflow if too much beverage is filled into the bottle. Please pour out some beverage from the bottle if the beverage above the maximum level.

Approx. 1cm
Beverage
Maximum level
- Close the drinking cap set and lid set tightly**
 - Attach the drinking cap set on the bottle by turning clockwise.
 - Attach the drinking cap set
 - Close the lid
 - Close the lid set by turning clockwise.

※ Please make sure the drinking cap set and lid set are set properly.
- Enjoy your beverage**
 - Turn the lid set anti-clockwise with the bottle stand upright as shown on the below drawing. ※The drinking cap will show up after turning the lid anti-clockwise to 180 degree.
 - Tilt the bottle and enjoy your beverage with the drinking cap. Tilt the product slowly when drinking hot beverages. (Due to the vacuum insulation, the outside of the bottle will not become hot. Please use with caution when drinking.)

① Turn the lid anti-clockwise. (Half Turn to 180 degree)

② Drinking cap

- Close the lid tightly after enjoying your beverage**
 - Put the bottle upright and then close the lid by turning the lid clockwise.
 - Close the lid

HOW TO TAKE CARE OF YOUR BOTTLE

- ◆ Please remember to clean your bottle after every use.
- ◆ Please use soft sponge only when clean your bottle.
- ◆ To prevent unpleasant odor, please clean your bottle thoroughly.

Outer bottle, lid set, drinking cap set

Please wash the outer bottle, lid set and drinking cap set with warm water and then wipe dry with dry cloth. Please remove the lid set and drinking cap set before washing.

Inner bottle

Please use a soft sponge with handle to wash the inner bottle thoroughly.

Gasket

It may cause water leakage if there is a foreign object on the gasket. Remove the gaskets from the lid or drinking cap. Wash with warm water and then wipe the gaskets with dry cloth. After that, refer to the "How to install the gasket" section to reinstall the gaskets correctly.

WHEN CLEANING YOUR BOTTLE

Please read this manual thoroughly before clean your bottle.

- Do not use chlorine type bleach.
- Do not clean with thinner, benzene, abrasive cleaners or other harsh cleaners.
- Do not boil the bottle, lid set to sanitize or clean them with dish washer or dish dryer.
- It is ok to wash the bottle with water but do not soak in water for an extended period of time.
- Wipe moisture off thoroughly after clean to prevent water stains or rusting.
- Make sure to clean the beverage stains on the bottle thoroughly. Wipe the bottle with a dry cloth and allow all the parts to air dry before storage.

AAS·AAT

AAS·AAT